


Dryvit Systems, Inc.
Design No. DSI/WDEIFS 30-05
Exterior Wall Systems
Dryvit OUTSULATION® PLUS MD Over Nudura ICF
NFPA 285 and NFPA 268
Rating: Meets Conditions of Acceptance



- 1. ICF WALL ASSEMBLY: Construct a wall using Nudura Insulated Concrete Forms (ICF) where the outer EPS insulation layer shall have a density of 1.35 pcf and a thickness of either 2-5/8 in. or 4 in.
- **2. WATER-RESISTIVE BARRIER:** Apply Tremco ExoAir 230 Weather Resistive Barrier to the ICF in accordance with manufacturer's instructions.
- **3. ADHESIVE:** Install Dryvit Primus, Genesis, or Genesis DM adhesive to the back side of the insulation board using a notched trowel measuring 1/4 in. wide x 3/8 in. deep, with notches spaced 1-1/2 in. on center (oc). Apply adhesive vertically to represent a drainage plane.
- **4. INSULATION BOARD:** Secure insulation board using adhesive. Install one of the following:



Division 07 – Thermal and Moisture Protection 07 24 00 Exterior Insulation and Finish Systems 07 24 19 Water-Drainage Exterior Insulation and Finish Stems

- A. When the Nudura ICF has an outer layer that is 2-5/8 in. thick, a max. of 9.375 in. thick, 1 pcf EPS foam insulation board may be adhered over the Tremco ExoAir 230 using the notched trowel specified in Item 3
- B. When the Nudura ICF has an outer layer that is 4 in. thick, a max. of 7.6 in. thick, 1 pcf EPS foam insulation board may be adhered over the Tremco ExoAir 230 using the notched trowel specified in Item 3.
- 5. BASE COAT: Apply one of the following base coat applications to the exterior side of the insulation board. After the initial coat, apply reinforcing mesh and then additional coats so the mesh is completely embedded.
 - A. DRYVIT PRIMUS ADHESIVE/BASE COAT Mixed at a 1:1 ratio by weight with Type GU Portland cement (a small amount of water may be added to achieve working viscosity) or,
 - B. PRIMUS DM ADHESIVE/BASE COAT Mixed at a 4:1 ratio with clean potable water or,

- C. GENESIS ADHESIVE/BASE COAT Mixed at 1:1 ratio by weight with Type GU Portland cement (a small amount of water may be added to achieve working viscosity).
- D. GENESIS DM ADHESIVE/BASE COAT Mixed at a 4:1 ratio with clean potable water.
- 6. **REINFORCING MESH:** Apply Dryvit meshes "Standard®", "Standard® Plus", or "Intermediate Mesh," with weights from 4.3 12.0 oz/yd², applied with edges overlapped 3 in. (75 mm) min., and embedded into the base coat. The fiberglass mesh is back-wrapped at the panel edges and joints of the substrate to encapsulate the insulation board. For additional impact resistance, a layer of Dryvit Panzer® Meshes 15.0 20.0 oz/yd² may be applied to the system prior to the application of standard meshes, in accordance with the manufacturer's application procedures.
- **7. FINISH COAT:** Apply Dryvit "DPR" finish coats over the base coat in accordance with Dryvit's installation guidelines for the specific finish using stainless steel trowel.

Consult the listing report on the Directory of Building Products (https://bpdirectory.intertek.com) for the edition of the standard(s) evaluated.

Compliance of the assembly described in this Design Listing with the referenced standard relies on verification that the assembly constructed in the field is consistent with that described herein. Intertek certified products may be verified by the approved Intertek label; other products must be verified by the Authority Having Jurisdiction as meeting the specifications stated herein.

Version: 09 June 2021 SFT-BC-OP-19i